



## Dismantling Instructions The Boxer Bed MK II

Help Line 01327 226275

### Dismantling the Boxer Bed Mark II

*This requires two people.*

Remove the mattress and empty the contents of the drawers

Remove all drawers and the bedside table/drawers

Undo the slat fixing screws (2) and remove the slats (3).

From behind the headboard, remove the two woodscrews (1) connecting the headboard to the side surround rails.

Undo the fixing screws (15 and 19) and remove the side surround rails (7).

Remove the centre support rail (4) by gently tapping it from underneath at each end with a mallet, to split the connectors.

Disconnect the side carcasses from the headboard by removing the machine screws (17) and connectors (18) using the allen key provided.

Undo the four carcass connecting screws (6) from inside the end drawer unit. You may require help to hold the head of the screws in the side drawer units to prevent them turning.

Lift and remove each side carcass (5) in turn from the bed assembly.

Remove the two machine screws (15) from each side, connecting the headboard (18) to the metal under-frame (13). Lift the headboard clear.

Carefully lift the headboard ends of the metal under-frame (13) until the end carcass (8) is standing on its face, with the metal side-rails in the vertical position. The metal rails can be detached from the carcass by undoing the castor (10) with a 19mm (3/4") open ended spanner and the fixing screw (11) using the allen key provided.

For assembly of the bed, carry out the procedure in reverse order.

